

# **MAKE GOOD MULTI SKIM FINISH** **APPLICATION GUIDE**



**STEP 1: Mix to a smooth (lump free) consistency**

**STEP 2: Apply 1st coat (1mm for board/2mm for over skim)**

 **Wait 15-20 minutes depending on the substrate/suction** 

**STEP 3: Apply 2nd coat (1mm thick for all surfaces)**

 **Wait 15-20 minutes depending on the substrate/suction** 


**STEP 4: First Trowel - standard steel trowel**

**STEP 5: Second Trowel - standard steel trowel**

 **When colour changes appear, wet trowel for third pass** 

**STEP 6: Third Trowel (wet) - mediflex trowel**

**STEP 7: FINAL polish - superflex trowel**

 If any signs of bubbling appear, leave alone and let it 'pull-in' before trying to trowel, this will avoid tearing.



Need help? Call our technical helpline . Tel: (+44) 0121 369 0570  
select 'OPTION 3' then select 'OPTION 1'